

VI.5.3D-HISTWYRS PROGRAM FCST HCL TECHNIQUE HISTWYRS

Purpose

Technique HISTWYRS sets the historical water years to be simulated by Function ESP.

This Technique must be on and the Arguments given non-zero values to run Function ESP.

Valid values are NO (0) and YES (1).

The Global default is NO (0).

This Technique is Universal.

Form of Input

HISTWYRS inityear lastyear

where inityear is the initial historical water year
lastyear is the last historical water year

Example

HISTWYRS 1950 1975

Water years 1950 through 1975 will be used for the ESP simulation.